



Remove power  
before you connect  
the server panel

! 23-37 kg  
50-80 lbs

**CAUTION:**  
Fans must be replaced within  
48 hours of removal to  
prevent a system shutdown.

**CAUTION:**  
Overheat warning. Do not  
operate the server for  
extended periods without  
the server panel.

**WARNING:**  
 Hot Surface